

REPLACEMENT PARTS GUIDE

3E Series - 3038E Compact Utility Tractors (HJ120004 -) (World Wide Edition)

ENGINE

DIESEL PARTICULATE FILTER (DPF)

[MIA884403](#)

See your John Deere™ dealer or qualified service provider.

PRIMARY FUEL FILTER

[MIU800645](#)

SECONDARY FUEL FILTER

[MIU803127](#)

Replace after every 400 hours or annually, whichever occurs first.

OIL FILTER

[M806419](#)

Replace after every 200 hours or annually, whichever occurs first.

FUEL/ WATER SEPARATOR

[M811032](#)

Replace after every 400 hours or annually, whichever occurs first.

TRANSMISSION / HYDRAULIC



OIL FILTER

[LVA14703](#)

Replace after every 400 hours.



OIL FILTER

[LVA16054](#)

Replace after initial 50 hours, then every 400 hours.



FILTER PAK

[TA26997](#)

Each kit contains above filters, offering a complete solution for your maintenance needs to keep your tractor running at peak performance.



JOHN DEERE

Genuine Parts and Service

CAPACITIES

3E Series - 3038E Compact Utility Tractors (HJ120004 -) (World Wide Edition)

CAPACITIES (Approximate):

Fuel Tank:

..... 23.5 L (6.2 gal)

Cooling System:

Cool-Gard™ II

..... 4.8 L (5.1 qt)

Crankcase with Filter:

Plus-50™

..... 4 L (4.2 qt)

Transmission and Hydraulic System:

Hy-Gard™

..... 21 L (5.5 gal)

Front Axle:

Hy-Gard™

..... 3.2 L (3.4 qt)

REPLACEMENT PARTS GUIDE

3E Series - 3038E Compact Utility Tractors (HJ120004 -) (World Wide Edition)




ENGINE



BRAKE DISK
[LVA14661](#)

1



CLUTCH DISK
[SJ13448](#)

2



BATTERY
[TY27831B](#)

3



ALTERNATOR
[LVA12467](#) (1500 RPM)
[MIA884643](#) (5000 RPM)

4



FAN BELT DRIVE
[LVU33849](#) (LGTH = 975 mm)
[LVU30203](#) (LGTH = 995 mm)

5

CAB



SEAT
[LVA22544](#) (FOR EUROPE)
[LVA23687](#)

6

AXLE



TIE ROD
[LVA15994](#) (ASSEMBLY)
[LVA15995](#) (RH)
[LVA15996](#) (LH)

7



JOHN DEERE
Genuine Parts and Service