

# REPLACEMENT PARTS GUIDE

## 3045R Compact Utility Tractor (1LV3045RKHJ200001- )(Europe Edition)

### ENGINE

#### ENGINE OIL



[TY26668](#) (John Deere Plus-50™ II Premium)  
(10W-30) (5.7 L (1.5 gal)) (WITH FILTER)  
Change every 200 hrs/ Annually.

#### SPIN-ON FUEL FILTER



[MIU800645](#)  
Change every 400 hrs/ Annually.

#### AIR FILTER

[RE68048](#) (PRIMARY)

[RE68049](#) (SECONDARY)

Service every 600 hrs. Change as required.

#### JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)

GREASE GUN

[TY26183](#)

Change As Required.

#### OIL FILTER

[M806419](#)

Change every 200 hrs/ Annually.

#### FUEL-WATER SEPARATOR

[AM881823](#) (SEPARATOR)

[M811032](#) (FILTER ELEMENT)

Change every 400 hrs.

### AXLE

#### TIE ROD

[LVA19527](#) (MFWD)

[LVA10747](#) (SCV, BOOM LINKAGE, OOS)

[LVA10748](#) (SCV, BUCKET LINKAGE, OOS)

#### FRONT AXLE OIL

[TY22062](#) (John Deere Hy-Gard™)  
(4.8 L (1.3 gal))

Change every 600 hrs.



### ELECTRICAL

#### KEY

[RE183935](#)

#### ROTARY SWITCH

[LVA21501](#) (14 V)

#### WET DISCHARGE BATTERY

[TY27831B](#) (12 V, 45 AH)

#### LED WORK LIGHT

[AM143579](#) (12 V)

#### HEADLIGHT

[LVA23716](#) (HALOGEN, DRIVING LIGHT, 12V)

#### V - BELT

[LVU29376](#) (FOR ALTERNATOR) (75 A)  
(LGTH = 1112 mm)

[LVU29375](#) (HVAC) (LGTH = 1508 mm)

### FUEL TANK FILLER CAP

#### FILLER CAP

[AL213202](#)

### CAB (IF EQUIPPED)

#### AIR FILTER

[MIU10010](#) (FRESH)

[MIU10011](#) (RECIRCULATION)

Service or Change every 50 hrs.

### TRANSMISSION/ HYDRAULIC

#### TRANSMISSION/HYDRAULIC OIL

[TY22000](#) (John Deere Low Hy-Gard™)  
(25.7 L (6.8 gal))

Change every 400 hrs.

#### OIL FILTER

[LVA12726](#) (TRANSMISSION INLINE  
HYDRAULIC OIL FILTER)

[LVA13065](#) (HYDRAULIC SUCTION FILTER  
ELEMENT)

Change every 400 hrs.