

REPLACEMENT PARTS GUIDE

753JH (PIN: 1T0753JH_ _C220453—)



HYDRAULIC OIL RETURN FILTER

[F061786](#)

Interval (hrs) - 2000.

ENGINE ROCKER ARM COVER GASKET

[R527884](#)

Interval (hrs) - 2000

PRIMARY AND FINAL FUEL FILTER ELEMENTS KIT

[RE525523](#)

Interval (hrs) - 500



AUXILIARY FUEL FILTER ELEMENT

[AT365870](#)

Interval (hrs) - 500



FINAL FUEL FILTER PRE-SCREEN ELEMENT

[R502778](#)

Interval (hrs) - 500.



ENGINE OIL FILTER

[RE509672](#)

Interval (hrs) - 500.



HYDRAULIC BREATHER FILTER

[F122930](#)

Interval (hrs) - 2000.



ENGINE CRANKSHAFT DAMPENER KEY

[R523306](#)

Interval (hrs) - 4000.



ENGINE AIR FILTER ELEMENT - PRIMARY

[AT175223](#)

Interval (hrs) - As Required



ENGINE AIR FILTER ELEMENT - SECONDARY

[AT175224](#)

Interval (hrs) - As Required.



SERPENTINE BELT

[T428855](#)

Interval (hrs) - As Required.



ENGINE CRANKSHAFT DAMPER

[RE520465](#)

Interval (hrs) - 4000.



CAB FRESH AIR FILTER

[700093800](#)

Interval (hrs) - As Required.



CAB RECIRCULATING AIR FILTER

[F436088](#)

Interval (hrs) - As Required.



ENGINE CRANKSHAFT DAMPER

[RE57604](#)

Interval (hrs) - 4000.











JOHN DEERE

Genuine Parts and Service

OILS AND CAPACITIES INFORMATION

753JH (PIN: 1T0753JH__C220453—)

Part Description		Part Number	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil		TY26674 ³	31.0 L (8.2 gal)	500
API GL-5 Gear Oil, Swing Drive Gear Case		TY26372 ³	4.5 L (4.8 qt.)	1000
API GL-5 Gear Oil, Track Planetary Gear Case (each)		TY26372 ³	4.8 L (5.1 qt.)	500
John Deere Hy-Gard™ Pump Drive Gear Case Oil		TY6354 ³	6.2 L (6.5 qt.)	1000
DEXRON® III ATF Enclosure Door Pump Oil		TY26459	1.6 L (1.7 qt.)	2000
John Deere Plus-50™ II Hydraulic Oil		TY26671 ³	136.0 L (36.0 gal.)	2000
COOL-GARD™ II Pre-Mix		TY26575	36.0 L (9.5 gal.)	6000
Coolant Extender		TY26603	As Required	As Required

OILS AND CAPACITIES INFORMATION

753JH (PIN: 1T0753JH__C220453—)

Part Description	Part Number	Qty or capacity	Change Interval In Hours
Fluid Analysis Kits⁴			
Diesel Engine Oil	AT346594	1	250
Hydraulic Oil	AT346594	1	500
Track Drive Planetary Oil	AT346594	2	500
Swing Drive Gear Case Oil	AT346594	1	500
Pump Drive Gear Case Oil	AT346594	1	500
Diesel Fuel	AT180344	1	500
Engine Coolant	TY27787	1	500
COOL-GARD™ II Test Strips	TY26605	1	1000

³ See operator's manual for recommended oil type and oil viscosities based on operating temperatures.

⁴ Based on fluid analysis results, intervals may need to be adjusted for your operating conditions. Consult your local John Deere dealer.

Plus-50 is a trademark of Deere & Company
 Hydra is a trademark of Deere & Company
 Hy-Gard is a trademark of Deere & Company
 Cool-Gard is a trademark of Deere & Company



CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

Service Intervals

As Required	
• Inspect serpentine belt	• Check and clean cab fresh air and cab recirculation air filters
• Inspect undercarriage frame joints	• Add coolant extender as indicated by COOL-GARD™ II test strips
• Replace engine air filter elements (replace secondary element every third primary element cleaning or change)	
Every 10 Hours or Daily	
• Lubricate hoist (boom) joints and cylinder ends	• Check pump drive gear case oil level
• Check and clean radiator pre-screen	• Check swing drive gear case oil level
• Check coolant level	• Check hydraulic oil level
• Check and clean cooling system and condenser fins	• Check fire extinguisher
• Fire suppression system—if equipped ¹	• Check and adjust track sag
• Check engine oil level	• Lubricate swing pinion and bearing
• Check and drain fuel/water separator	• Lubricate leveler pivot joints (759J/JH)
• Check and drain auxiliary fuel filter/water separator—if equipped	
Every 100 Hours	
• Check track drive planetary oil level	• Check engine rpm
• Lubricate door hinges	• Check oil level in track idler assembly
• Lubricate secondary exit latches and knobs	• Lubricate swing gear case bearing
• Check skylight latch tension	• Lubricate rotary manifold (759J/JH)
Initial Service - 250 Hours	
• Drain and refill engine break-in oil and replace filter	• Check planetary and sprocket mounting cap screw torque
• Drain and refill pump drive gear case oil	• Check swing bearing cap screw torque
• Drain and refill swing gear case oil	• Check lower roller mounting cap screw torque
• Check hydraulic pressures	• Check track shoe cap screw torque
• Drain and refill track drive planetary oil	
Every 500 Hours	
• Drain and refill engine oil and replace filter	• Take engine oil sample
• Drain and refill track drive planetary oil	• Take pump drive gear case oil sample
• Check enclosure door pump oil level	• Take swing gear case oil sample
• Check battery electrolyte level	• Take track drive planetary oil sample
• Replace fuel/water separator filter	• Take hydraulic oil sample
• Replace final fuel filter	• Take coolant sample
• Replace auxiliary fuel filter/water separator—if equipped	• Take diesel fuel sample
Every 1000 Hours	
• Drain and refill pump drive gear case oil	• Check coolant
• Drain and refill swing gear case oil	
Every 2000 Hours	
• Check and adjust engine valve lash clearance	• Replace hydraulic oil return filters
• Drain and refill enclosure door pump oil	• Replace hydraulic breather filter
• Drain and refill hydraulic oil	
Every 4000 Hours	
• Replace engine crankshaft dampers	
Every 6000 Hours	
• Drain and refill engine coolant	