

# REPLACEMENT PARTS GUIDE

## 5EF Series Tractor - 5075EF (South American Edition)

### ENGINE



#### PRIMARY FUEL FILTER [RE62418](#)

Replace after every 250 hours and annually.



#### OIL FILTER [RE507204](#) (FOR INDIA ONLY) [T19044](#) (FOR EXPORT)

Replace initially after 100 hours and every 375 hours and annually.



### ENGINE



#### PRIMARY AIR FILTER

[RE282286](#)



#### SECONDARY AIR FILTER [RE282287](#)

Replace after cleaning 6 times or annually which ever occurs first.

### TRANSMISSION



#### HYDRAULIC OIL FILTER [RE45864](#)

Replace initially after 100 hours and 1500 hours.

# CAPACITIES

## 5EF Series Tractor - 5075EF (South American Edition)

### CAPACITIES (Approximate):

#### *Fuel Tank:*

..... 70 L (18.5 gal)

#### *Cooling System:*

##### Cool-Gard™ II

..... 11 L (2.9 gal)

#### Hy-Gard™

..... 40 L (10.57 gal)

#### *Transmission and Hydraulic System:*

# REPLACEMENT PARTS GUIDE

## 5EF Series Tractor - 5075EF (South American Edition)

### ENGINE




#### BRAKE DISK

[SJ17870](#) (REAR WHEEL)

[L77358](#) (ACTUATING DISK)

[RE45938](#) (MFWD)



#### CLUTCH DISK

[RE227648](#) (PTO)

[SJ25811](#) (TRACTION)



#### BATTERY

[SJ10989](#)



#### ALTERNATOR

[RE234714](#)



#### FAN BELT DRIVE

[R216949](#) (FAN ASSEMBLY)  
(LGTH = 1360 mm)



### CAB



#### SEAT

[SJ17647](#) (ASSEMBLY)

### AXLE



#### TIE ROD

[RE61835](#) (ASSEMBLY)

[RE61836](#) (RH)

[RE61833](#) (LH)



**JOHN DEERE**  
Genuine Parts and Service