

FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

6030 Series Premium Tractors - 6230, 6330 and 6430

CAB

ACTIVATED CARBON FILTER - [L209778](#) (2)

Never clean. Replace after every 500 hours or 1 year or with Engine Primary Air Filter, whichever occurs first.



CAB

RECIRCULATION AIR FILTER With A/C - [L214634](#) (2) Without A/C - [L152026](#) (2)

Clean as required. Replace after every 1500 hours, or 2 years, or with Engine Primary Air Filter, whichever occurs first.



CAB

KIT, ACTIVATED CARBON FILTER - [AL158986](#)

Never clean. Replace after every 500 hours or 1 year or with Engine Primary Air Filter, whichever occurs first.



CAB

FRESH AIR FILTER HEAVY-DUTY - [AL225554](#) (2)


Clean as required. Replace after every 1500 hours, or 2 years, or with Engine Primary Air Filter, whichever occurs first.



HYDRAULICS

OIL FILTER - [AL169573](#)

Replace after first 100 hours, then after first 750 hours and every 750 hours thereafter. Change Transmission Oil Filter as well.



(Click here for [capacity](#))

TRANSMISSION (without JD IVT™)

OIL FILTER - [AL221066](#)

Replace after first 100 hours, then after first 750 hours and every 750 hours thereafter. Change Hydraulic Oil Filter as well.

(Click here for [capacity](#))



TRANSMISSION (with JD IVT™)

OIL FILTER - [AL206482](#)

Replace after first 100 hours, then after first 750 hours and every 750 hours thereafter. Change Hydraulic Oil Filter as well.

(Click here for [capacity](#))



ENGINE

PRIMARY FUEL FILTER - [RE546336](#) FINAL FUEL FILTER - [RE526557](#)

Replace after every 500 hours.



ENGINE

PRIMARY AIR FILTER - [AL172780](#)

Clean up to 5 times. Replace after every 1500 hours or 2 years, whichever occurs first.



ENGINE

SECONDARY AIR FILTER - [AL150288](#)

Replace at every fifth change of Primary Air Filter, or after 1500 hours, whichever occurs first.



FRONT PTO

OIL FILTER - [L114404](#)

Replace after every 750 hours.

(Click here for [capacity](#))



ENGINE

OIL FILTER - [RE504836](#)

Replace after first 100 hours, then after first 500 hours and every 500 hours thereafter or annually. The extended 500 hour interval is allowed only if using Plus-50™ II oil, JD OEM Oil Filter and diesel fuel with sulfur content less than 15mg/kg (15 ppm). Change Oil and Filter after every 250 hours, if conditions are not met.

(Click here for [capacity](#))



JOHN DEERE

Genuine Parts and Service

CAPACITIES

6030 Series Premium Tractors - 6230, 6330 and 6430

CAPACITIES (Approximate):

Fuel Tank:

.....	116 L (30.6 gal)
.....	185 L (48.9 gal)

Cooling System: Cool-Gard™ II

.....	29 L (7.7 gal)
-------	----------------

Crankcase with Filter: Plus-50™

.....	16 L (4.2 gal)
-------	----------------

Front PTO: Hy-Gard™

.....	3.5 L (0.9 gal)
-------	-----------------

Transmission and Hydraulic System: Hy-Gard™

PowrQuad™ Plus with 16/16 Gears	49 L (12.9 gal)
PowrQuad™ Plus with 24/24 Gears	50 L (13.2 gal)
AutoQuad™ Plus	50 L (13.2 gal)
IVT™	60 L (15.9 gal)
Extra with Creeper	1 L (0.3 gal)
Extra with Front-Wheel Drive.....	3 L (0.8 gal)
Extra with TLS™ Axle	3 L (0.8 gal)

Front-Wheel Drive: Hy-Gard™

Axle Housing	6.5 L (1.7 gal)
Final Drives.....	0.95 L (0.25 gal)

[Return to Filter Overview](#)

