

REPLACEMENT PARTS GUIDE

244K-II Compact 4WD Loader (PIN: 1LU244KT __B042870—)



PRIMARY FUEL FILTER

[MIU802421](#)

Interval (hrs) - 500.



FINAL FUEL FILTER

[MIU805005](#)

Interval (hrs) - 500.



ENGINE OIL FILTER—244K

[MIU800650](#)

Interval (hrs) - 500.



PRIMARY AIR CLEANER ELEMENT

[KV16429](#)

Interval (hrs) - 1000.



ENGINE ROCKER ARM COVER GASKET

[MIU803967](#)

Interval (hrs) - 1500.



V-BELT ALTERNATOR (S.N. —043553)

[MIU803581](#)

Interval (hrs) - 100.



V-BELT ALTERNATOR (S.N. 043554—)

[AT212062](#)

Interval (hrs) - 100.



SECONDARY AIR CLEANER ELEMENT

[AT171854](#)

Interval (hrs) - 1000.



CAB RECIRCULATION AIR FILTER

[LW12232136](#)

Interval (hrs) - 250.



HYDRAULIC SYSTEM RETURN SUCTION FILTER

[AT312905](#)

Interval (hrs) - 500.



HYDRAULIC OIL RESERVOIR BREATHER

[AT334649](#)

Interval (hrs) - 1000.



V-BELT AIR CONDITIONER

[CH16856](#)

Interval (hrs) - 100.



AIR CLEANER DUST UNLOADER VALVE

[AM108172](#)

Interval (hrs) - 1000.



JOHN DEERE
Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

OIL AND CAPACITIES INFORMATION

244K-II Compact 4WD Loader (PIN: 1LU244KT __B042870—)

Part Description	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil	10.2 L (2.7 gal)	500
API GL-5 Differential, Gear Case, and Final Drive Oil ¹ —244K-II”	12.3 L (3.2 gal)	1000
John Deere Hydrau™ Hydraulic Oil ¹ —244K-II”	55.0 L (14.5 gal)	2000
John Deere Cool-Gard™ II Premix—244K-II”	11.0 L (2.9 gal.)	6000
Fluid Analysis Kits ²		
Diesel Engine Oil	1	250
Hydraulic Oil	1	500
Gear Case Oil	1	500
Differential Oil	2	500
Final Drive Oil	4	500
Diesel Fuel	1	500
Engine Coolant	1	1000
¹ See operator's manual for recommended oil type and oil viscosities based on operating temperatures. ² Based on fluid analysis results, intervals may need to be adjusted for operating conditions. Consult an authorized John Deere dealer.		

Plus-50 is a trademark of Deere & Company

Hydrau is a trademark of Deere & Company

Cool-Gard is a trademark of Deere & Company



Service Intervals

As Required	
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Lubricate door hinges
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Inspect tires and check tire pressure
<input type="checkbox"/> Check air cleaner elements	<input type="checkbox"/> Service exhaust filter
<input type="checkbox"/> Check wheel bolt torque	
Every 10 Hours or Daily	
<input type="checkbox"/> Check recovery tank coolant level	<input type="checkbox"/> Check hydraulic oil level
<input type="checkbox"/> Check engine oil level	<input type="checkbox"/> Lubricate Quik-Tatch™ pins and bushings
<input type="checkbox"/> Clean air cleaner dust unloader valve	
Every 50 Hours	
<input type="checkbox"/> Lubricate loader linkage and cylinder pivots	<input type="checkbox"/> Lubricate frame hinge pivots
<input type="checkbox"/> Lubricate drive shaft	<input type="checkbox"/> Lubricate rear oscillating axle
<input type="checkbox"/> Lubricate steering cylinder	
Every 100 Hours	
<input type="checkbox"/> Check and adjust accessory drive belt tension	
Every 250 Hours	
<input type="checkbox"/> Check service (drum) brake oil level	<input type="checkbox"/> Clean or replace cab recirculation air filter
<input type="checkbox"/> Take engine oil sample	
Every 500 Hours	
<input type="checkbox"/> Lubricate rear axle steering pivots	<input type="checkbox"/> Check front differential oil level
<input type="checkbox"/> Check final drives oil level	<input type="checkbox"/> Replace hydraulic system return suction filter
<input type="checkbox"/> Check and clean cooling package	<input type="checkbox"/> Take hydraulic oil sample
<input type="checkbox"/> Check rear differential and gear case oil levels	<input type="checkbox"/> Take gear case oil sample
<input type="checkbox"/> Change engine oil and replace oil filter	<input type="checkbox"/> Take differential oil sample
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Take final drive oil sample
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Take diesel fuel sample
<input type="checkbox"/> Check air intake hoses	<input type="checkbox"/> Take engine coolant sample
<input type="checkbox"/> Check and adjust inching linkage	
Every 1000 Hours	
<input type="checkbox"/> Check service (drum) brake pads	<input type="checkbox"/> Replace air cleaner elements
<input type="checkbox"/> Change final drive oil	<input type="checkbox"/> Replace air cleaner dust unloader valve
<input type="checkbox"/> Change rear differential and gear case oil	<input type="checkbox"/> Replace hydraulic oil reservoir breather
<input type="checkbox"/> Change front differential oil	<input type="checkbox"/> Replace cab recirculation air filter
<input type="checkbox"/> Clean engine crankcase vent	<input type="checkbox"/> Check coolant condition
Every 1500 Hours	
<input type="checkbox"/> Check and adjust engine valve lash	
Every 2000 Hours	
<input type="checkbox"/> Change hydraulic oil	<input type="checkbox"/> Clean hydraulic system strainer
Every 6000 Hours	
<input type="checkbox"/> Drain, flush, and refill cooling system	