

REPLACEMENT PARTS GUIDE

5040D Tractor

ENGINE



PRIMARY FUEL FILTER
[RE508953](#)
FINAL FUEL FILTER
[RE508954](#)

Replace after every 250 hours and as required.



OIL FILTER
[RE507204](#) (For India)
[T19044](#) (For Export)

Change every 250 hours and 500 hours.



PRIMARY AIR FILTER
[RE68048](#)
SECONDARY AIR FILTER
[RE68049](#)

Change after every 250 hours or annually which ever comes first.



HYDRAULIC



OIL FILTER
[RE45864](#)

Replace after every 500 hours and every 1250 hours



JOHN DEERE
Genuine Parts and Service

CAPACITIES

5040D Tractor

CAPACITIES (Approximate):

Fuel Tank:

..... 60 L (13.69 gal)

Crankcase including Filter Change: Plus-50™ II

..... 6.5 L (1.42 gal)

Transmission and Hydraulic System:

Hy-Gard™ Oil Axle

..... 32 L (7.03 gal)

Mechanical Front Wheel Drive (MFWD) Axle Housing:

MFWD Axle Oil Hy-Gard™

..... 5.9 L (1.29 gal)


[Return to Filter Overview](#)





REPLACEMENT PARTS GUIDE


5040D Tractor

ENGINE

 **BRAKE DISK**
[SJ18395](#)


 **CLUTCH DISK**
[RE242274](#) (PTO)
[SJ29350](#) (TRACTION)

 **ALTERNATOR**
[RE258846](#) (40 A)


 **FAN BELT DRIVE**
[SU63793](#)
(LGTH = 1340 mm)



CAB

 **SEAT**
[RE212692](#) (BACK)
[RE73192](#) (BOTTOM)
[SJ34660](#) (W/ SEAT BELT)

AXLE

 **TIE ROD**
[SJ14021](#) (TIE ROD ASSEMBLY) (MFWD)
[SJ14025](#) (LH) (MFWD)
[SJ14024](#) (RH) (MFWD)
[LVA14171](#) (HYDRAULIC CYLINDER) (MFWD)
[RE216708](#) (ROCKSHAFT LINKAGE) (W/ FCV)
[R141317](#) (ROCKSHAFT TOP LINK BRACKET, W/ FCV)
[R225906](#) (ROCKSHAFT TOP LINK BRACKET, W/ SCV)

