

CommandARM™ Layout

Operation Controls

- 1 Engine Speed Selection
- 2 Solution Pump [on/off]
- 3 Agitation [on/off]
- 4 Tread Adjust
- 5 Section Valve [on/off]
- 6 Display Controls
- 7 Rate Selection Knob
- 8 Modulated Brake Switch
- 9 Park Brake
- 10 Ladder [up/down]
- 11 Transport Lock
- 12 Slip Control
- 13 Fence Row Nozzles

Hydro Handle Controls

- 14 Foam Markers
- 15 Boom Indexing
- 16 Center Frame Height
- 17 Speed Range Selection
- 18 Tilt
- 19 Master Spray On

Operator Environment Controls

- 20 Climate Controls ClimaTrak™
- 21 Radio Controls
- 22 Light Controls

