

# FILTER OVERVIEW WITH SERVICE INTERVALS

## 9020 Series Tractors

### ENGINE

SECONDARY AIR FILTER (9120-9620) – [RE63932](#)  
Replace annually and as required.

### ENGINE

PRIMARY AIR FILTER (9120-9620) – [RE63931](#)  
Replace annually and as required.

### ENGINE

OIL FILTER (9120) – [RE509672](#)  
OIL FILTER (9220-9620) – [RE58935](#)  
Replace after 100 hours and then every 250 hours.  
Initial oil and filter change is 100 hours maximum of operation. Scheduled interval can be extended to 375 hours if PLUS-50™ oil and a John Deere filter are used.

### TRANSMISSION

OIL FILTER (9120-9620) – [RE174130](#)  
Replace after 100 and 750 hours, and then every 750 hours.

### ENGINE – 9220-9620

Single filter system – use with 6125HRW13/6125HRW15  
FUEL FILTER – [RE507284](#)  
Replace after 100 hours, then every 500 hours

Two filter system – use with 6125HRW16/6125HRW17/6125HRW18  
PRIMARY FUEL FILTER – [RE515345](#)  
SECONDARY FUEL FILTER – [RE506428](#)  
Replace every 250 hours.

**ENGINE – 9120**  
Single filter system, up to engine serial no. 232462  
FUEL FILTER – [RE522372](#)  
FUEL PRE FILTER – [R502778](#)  
Replace after 100 hours, then every 500 hours  
Two filter system, from engine serial no. 232463  
PRIMARY FUEL FILTER – [RE522687](#)  
SECONDARY FUEL FILTER – [RE522688](#)  
Replace every 250 hours.

### CAB

RECIRCULATION AIR FILTER (9120-9620) – [RE187966](#)  
Clean every 250 hours and replace annually.

### CAB

ACTIVATED CARBON RECIRCULATION AIR FILTER (9120-9520) – [RE199682](#)  
Do NOT clean. Change annually, after 500 hours, or as required.

### CAB

OIL, HIGH FLOW (Scraper Tractor, 9320-9520) – [T175002](#)  
Replace every 750 hours.

### CAB

FRESH AIR FILTER, HEAVY DUTY (9120-9620) – [RE67829](#)  
AIR FILTER, STANDARD (9120-9620) – [RE24619](#)  
Clean every 250 hours and replace annually.

### CAB

ACTIVATED CARBON AIR FILTER (9120-9520) – [RE199681](#)  
Do NOT clean. Change annually, after 500 hours, or as required.

### HYDRAULICS

HYDRAULIC OIL FILTER (9120-9620) – [RE174130](#)  
Replace after 100 and 750 hours, and then every 750 hours.

### HYDRAULICS

AIR, HYDRAULIC RESERVOIR (9120-9620) – [AT101565](#)  
Replace every 750 hours.



**JOHN DEERE**  
Genuine Parts and Service

April 2006. Subject to change without notice.