

# REPLACEMENT PARTS GUIDE

## 3025E Compact Utility Tractor

### ENGINE



#### ENGINE OIL

[TY26668](#) (10W-30 PLUS 50 II), (4.0 L (4.2 qt))  
(WITH FILTER)

Change after every 200 Hrs/Annually.



#### FUEL FILTER

[MIU800645](#)

Change after every 400 Hrs/Annually.



#### AIR FILTER

[M131802](#) (PRIMARY)

[M131803](#) (SECONDARY)

Change after every 400/600 Hrs/Annually.



#### JOHN DEERE SPECIAL PURPOSE GOLF AND TURF CUTTING UNIT GREASE

[TY6341](#)

#### GREASE GUN

[TY26183](#)

Change As Required.



#### OIL FILTER

[M806419](#)

Change after every 200 Hrs/Annually.



#### FILTER PAK

[LVA21037](#)



#### FUEL-WATER SEPARATOR

[AM881823](#) (SEPARATOR)

[M811032](#) (FILTER ELEMENT)

Change after every 400/600 Hrs/Annually.

### AXLE



#### TIE ROD

[LVA15994](#) (ASSEMBLY)

[LVA15996](#) (LH)

[LVA15995](#) (RH)



#### FRONT AXLE OIL

[TY22000](#) 3.2 L (3.4 qt)

Change every 600 Hrs.



### ELECTRICAL



#### KEY

[LVA17264](#)



#### HEAD LIGHT

[LVA14946](#) (NOT FOR USA AND CANADA)



#### ROTARY SWITCH

[LVU29433](#)



#### LED WORK LIGHT, OOS

[AM143579](#) (12 V) (FOR USA AND CANADA)



#### BATTERY

[TY26498](#) (12 V)

### FUEL & AIR



#### FILLER CAP

[TCU31996](#)



#### MUFFLER

[LVA14442](#)

### TRANSMISSION / HYDRAULIC



#### OIL FILTER

[LVA14703](#) (SUCTION)

[LVA16054](#) (TRANSMISSION)



#### TRANSMISSION / HYDRAULIC OIL

[TY22000](#) (21 L (5.5 gal))

Change after every 50/400 hrs.



#### V-BELT

[M801821](#) (LGTH = 986.03 mm,  
WIDTH = 12.7 mm, TK = 10.31 mm)