

JOHN DEERE PROTECT™

PROTECT YOUR PERFORMANCE. PROTECT YOUR TIME. PROTECT YOUR COST.

X and S Series Front-End Equipment



JOHN DEERE



Buyers of new John Deere front-end equipment for X and S Series combines can now **lock in annual maintenance costs**¹ and be in a better position to **prevent downtime** during harvest. It's all possible with a John Deere Protect™ Maintenance Plan.

Designed to **improve performance** and **efficiency** along with **reducing costs**, the Maintenance Plan is for MY21-22 front-end equipment. Available when purchased in conjunction with a PowerGard™ Limited or Comprehensive Protection Plan², John Deere Protect offers you a choice of coverage for the first 36 months/750 header hours or 36 months/1,000 header hours³ (**with no deductible**⁴ and **no additional charges**).

So what's included with each component of the John Deere Protect Maintenance Plan? See the back side of this flyer to learn more about expert inspections, maintenance events and the 3-year maintenance schedule.

MAINTENANCE

John Deere Protect Maintenance Plan⁵ includes:

- 3 Annual Expert Inspections (1 per calendar year)
- 3 Scheduled Maintenance Events (1 per calendar year)

Minimum PowerGard Limited coverage of 36 months or 1,000/1,250 hours must be purchased to match the John Deere Protect plan desired. Longer PowerGard plans can be purchased if desired.

¹Excludes diesel fuel, diesel exhaust fluid, and wear parts.

²PowerGard Comprehensive Protection Plan with a minimum term of 36 months/1,000 or 1,250 hours must be purchased separately to be eligible for John Deere Protect extended service plans. Additional details are included in the selling descriptions of each included plan.

³Not all models are equipped with hour meters. Combine engine hour readings may be used to determine coverage term for models without hour meters.

⁴PowerGard deductible applies to any failures under PowerGard coverage.

⁵For complete plan details, contact a participating dealer near you.

JOHN DEERE PROTECT™

PROTECT YOUR PERFORMANCE. PROTECT YOUR TIME. PROTECT YOUR COST.

X and S Series Front-End Equipment



JOHN DEERE



Expert Inspections

The John Deere Protect Maintenance Plan includes three end-of-season expert inspections to help make sure your front-end equipment is ready to run for next harvest. The 50-plus point inspection ensures that all critical areas of the front-end equipment are evaluated by an expert technician from your local dealer and identifies potential problems to help avoid expensive, unplanned downtime. Coverage term is 36 months/750 or 1,000 header hours.

Maintenance Events

The John Deere Protect Maintenance Plan includes three end-of-season preventive maintenance events to ensure your front-end equipment is properly maintained for the upcoming harvest. Local dealer expert technicians perform all maintenance and utilize Genuine John Deere parts and fluids. See chart for maintenance schedule details. In-season maintenance is not covered. Coverage term is 36 months/750 or 1,000 engine hours.

To learn more about the benefits of John Deere Protect, contact a participating John Deere Dealer.

JOHN DEERE PROTECT FRONT-END EQUIPMENT MAINTENANCE SCHEDULE

	YEAR 1	YEAR 2	YEAR 3
Folding Corn Head (CxF) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Replace Oil in Row Unit Drive Chains	■	■	■
Folding Corn Head (CxF) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■
Replace Oil in Row Unit Drive Chains	■	■	■
Replace Oil in Row Unit Gear Cases (if equipped)			■
Replace Oil in StalkMaster™ Front Gear Case (if equipped)			■
Replace Oil in StalkMaster™ Rear Gear Cases (if equipped)			■
Rigid Corn Head (CxR) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Replace Oil in Row Unit Drive Chains	■	■	■
Rigid Corn Head (CxR) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■
Replace Oil in Row Unit Drive Chains	■	■	■
Replace Oil in Row Unit Gear Cases (if equipped)			■
Replace Oil in StalkMaster™ Front Gear Case (if equipped)			■
Replace Oil in StalkMaster™ Rear Gear Cases (if equipped)			■
Hinged Frame Rigid Cutter (HDxR) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Hinged Frame Rigid Cutter (HDxR) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■
Replace Main Gear Case Oil			■
Replace Center Feed Drum Gear Case Oil			■
Replace Center Feed Belt Gear Case Oil			■
Hinged Frame Flex Cutter (HDxF) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Hinged Frame Flex Cutter (HDxF) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■
Replace Main Gear Case Oil			■
Replace Center Feed Drum Gear Case Oil			■
Replace Center Feed Belt Gear Case Oil			■
Rigid Frame Flex Cutter (RDxF) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Rigid Frame Flex Cutter (RDxF) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■
Replace Main Gear Case Oil			■
Belt Pickup (BP15) – 36 months/750 hours	200 – 250 hours	400 – 500 hours	600 – 750 hours
Lubricate all grease fittings	■	■	■
Belt Pickup (BP15) – 36 months/1000 hours	275 – 330 hours	550 – 660 hours	825 – 1000 hours
Lubricate all grease fittings	■	■	■