

# FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

## 2026R (HH200003 - ) Compact Utility Tractor

### ENGINE

#### INLINE FUEL FILTER - [AM116304](#)

Replace every 400 hours and annually.

(Click here for [capacity](#))



### ENGINE

#### FUEL FILTER - [MIU804763](#)

Replace after every 400 hours or annually, whichever occurs first.

(Click here for [capacity](#))



### ENGINE

#### OIL FILTER - [M806418](#)

Replace every 200 hours and annually if less than 400 hours of operation

(Click here for [capacity](#))



### TRANSMISSION

#### HYDRAULIC FILTER - [LVA16054](#)

Replace after first 50 hours and every 200 hours.


(Click here for [capacity](#))



### CAB

#### AIR FILTER - [HF20000823](#)

Clean or replace after every 50 hours and as required.




### ENGINE

#### PRIMARY AIR FILTER - [M113621](#) (- 200380), [LVU34503](#) (200381 -) SECONDARY AIR FILTER - [M123378](#) (- 200380), [LVU34504](#) (200381 -)

Replace every 400 hours and as required. Check and service every 10 hours/daily, every 200 hours and annually.

(Click here for [capacity](#))



**JOHN DEERE**

Genuine Parts and Service

# CAPACITIES

## 2026R (HH200003 - ) Compact Utility Tractor

**CAPACITIES (Approximate):**

**Fuel Tank:**

..... 20.4 L (5.3 gal)

**Cooling System:  
Cool-Gard™ II**

..... 3.7 L (0.8 gal)

**Crankcase with Filter:  
Plus-50™**

..... 2.7 L (0.6 gal)

**Transmission and Hydraulic System:  
Hy-Gard™**

..... 14.4 L (3.8 gal)

**Front Axle:  
Hy-Gard™**

..... 2.8 L (0.6 gal)

[Return to Filter Overview](#)

