

REPLACEMENT PARTS GUIDE

2036R Tractor (GH200001-) Europe Edition

ENGINE



OIL FILTER

[M806419](#)

Change every 200 Hrs.



ENGINE OIL

[TY26668](#) (10W - 30 PLUS 50 II)

Change every 200 Hrs.



PRIMARY AIR FILTER

[M131802](#)

Every 600 Hours.



SECONDARY AIR FILTER

[M131803](#)

Every 600 Hours.



CAB AIR FILTER

[HF235742801](#)

As Required.



JOHN DEERE MULTI-PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)



GREASE GUN

[TY26518](#)

Change As Required.



FUEL FILTER

[MIU800645](#)

Replace Yearly.



HYDRAULIC FILTER

[LVA16054](#)

Change every 400 Hrs.



V BELT

[LVU30203](#) (LGTH = 995 mm)



ELECTRICAL



KEY

[LVU33004](#)



ROTARY SWITCH

[LVA21501](#)



HEAD LIGHT

[LVA14946](#)



BATTERY

[TY27831B](#) (12V)



BRAKE SWITCH

[LVA13307](#)

FUEL & AIR



FILLER CAP

[AL213202](#)



MUFFLER

[LVA21057](#)

REPLACEMENT PARTS GUIDE

MOWER DECK - 60IN

MOWER BLADE

[M163983](#)

V BELT

[M136137](#) (LGTH = 3692 mm)



GAGE WHEELS

[TCU18744](#)

MULCH BLADE

[M168223](#)

REPLACEMENT PARTS GUIDE

MOWER DECK - 72IN

MOWER BLADE
[M141669](#)

V BELT
[M149866](#) (LGTH = 4085 mm)



GAGE WHEELS
[TCU18744](#)