

# REPLACEMENT PARTS GUIDE

## 3032E Tractor (PIN: 1LV3032E\*LL300001- ) (Worldwide Edition)

### ENGINE



#### ENGINE OIL

[TY26668](#) (John Deere Plus-50™ II Premium)  
(10W-30) 4.5 L (4.7 qt)) (WITH FILTER)  
Change every 400 hrs/ Annually



#### SPIN-ON FUEL FILTER

[MIU800645](#) (PRIMARY)  
[MIU803127](#) (SECONDARY)

Change after every 400 Hrs/Annually.



#### AIR FILTER

[M131802](#) (PRIMARY AIR CLEANER  
ELEMENT)  
[M131803](#) (SECONDARY AIR CLEANER  
ELEMENT)

Service every 600 hrs. Change as required.



#### JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY24416](#)  
[TY26183](#)

Change As Required.



#### OIL FILTER

[M806419](#)  
Change every 400 hrs/ Annually.



#### FUEL-WATER SEPARATOR

[MIU802421](#) (FILTER ELEMENT)  
Change after every 400 Hrs.



#### FILTER PAK

[LVA21037](#)

### AXLE



#### TIE ROD

[LVA15994](#) (ASSEMBLY)  
[LVA15995](#) (LH)  
[LVA15996](#) (RH)



#### FRONT AXLE OIL

[TY22035](#) (John Deere Low Viscosity  
Hy-Gard™) (3.8 L (4 qt))  
Change every 600 Hrs.

### ELECTRICAL



#### KEY

[LVU33004](#)



#### ROTARY SWITCH

[LVA21501](#) (14 V)



#### WET DISCHARGE BATTERY

[TY27831B](#) (12 V, 45 AH)



#### LED WORK LIGHT

[AM143579](#) (OOS) (12 V)



#### HEADLIGHT

[LVA23717](#) (LH) (TRAFFIC, DRIVING LIGHT)  
[LVA23716](#) (DRIVING LIGHT)



#### V - BELT

[LVU30203](#) (LGTH = 995 mm,  
WIDTH = 13.7 mm, TK = 9.5 mm)  
[LVU33849](#) (LGTH = 975 mm,  
WIDTH = 13.7 mm, TK = 9.5 mm)

### FUEL TANK FILLER CAP



[FILLER CAP](#)  
[AL213202](#)

### TRANSMISSION/ HYDRAULIC



#### TRANSMISSION/HYDRAULIC OIL

[TY22000](#) (John Deere Low Viscosity  
Hy-Gard™) (20.8 L (5.5 gal))  
Change every 400 hrs.



#### OIL FILTER

[LVA16054](#) (CHARGE HYDRAULIC FILTER)  
[LVA14703](#) (SUCTION HYDRAULIC FILTER)  
Change every 400 hrs.

