

REPLACEMENT PARTS GUIDE

4R Final Tier 4 (FT4) Series Compact Utility Tractors - 4044R(L00001-), 4052R(L00001-), 4066R(L00001-)

CAB

FRESH AIR FILTER

[MIU10010](#)

Clean or replace after every 50 hours and as required.

RECIRCULATION AIR FILTER

[MIU10011](#)-(2)

Clean or replace after every 50 hours and as required.

HYDRAULIC

HYDRAULIC OIL FILTER

[LVA10419](#)

Replace after every 400 hours.
(Click here for [capacity](#))

TRANSMISSION

OIL FILTER

[RE45864](#)

Replace after every 400 hours change every 1200 hours or 3 years.
(Click here for [capacity](#))

ENGINE

DIESEL PARTICULATE FILTER (DPF)

[MIU803276](#)-(4044R, 4052R)

[MIU802216](#)-(4052R, 4066R)

See your John Deere™ dealer or qualified service provider.

PRIMARY AIR FILTER

[RE68048](#)

SECONDARY AIR FILTER

[RE68049](#)

Check after every 600 hours and replace as required.

OIL FILTER

[M806419](#)

Replace after every 400 hours or annually, whichever occurs first.
(Click here for [capacity](#))

PRIMARY FUEL FILTER

[MIU802421](#)

FINAL FUEL FILTER

[MIU803127](#)

Replace after every 400 hours or annually, whichever occurs first.



CAPACITIES

4R Final Tier 4 (FT4) Series Compact Utility Tractors - 4044R(L00001-), 4052R(L00001-), 4066R(L00001-)

CAPACITIES (Approximate):

Fuel Tank:

Open Operator Station56.9 L (15 gal)
Cab55.6 L (14.7 gal)

Cooling System:

Cool-Gard™ II

Open Operator Station6.4 L (1.4 gal)
Cab7.6 L (1.7 gal)

Crankcase with Filter:

Plus-50™ II

..... 5.3 L (1.2 gal)

Transmission and Hydraulic System:

Hy-Gard™

.....47.3 L (12.5 gal)

Front Axle:

Hy-Gard™

.....5 L (1.3 gal)

[Return to Filter Overview](#)



JOHN DEERE
Genuine Parts and Service

REPLACEMENT PARTS GUIDE

4R Final Tier 4 (FT4) Series Compact Utility Tractors - 4044R(L00001-), 4052R(L00001-), 4066R(L00001-)



CAB

SEAT



[LVA19859](#) -(CAB)(4044R, 4052R)
[LVA19041](#) -(OOS)(4044R, 4066R)
[LVA21870](#) -(CAB)(W/ AIR SUSPENSION)
[LVA21870](#) -(CAB)(W/ AIR SUSPENSION)
[SU35474](#) -(BOTTOM)
[SU35475](#) -(BACK)
[LVA21871](#) -(OOS)(FOR EUROPE)

AXLE

TIE ROD



[LVA14951](#)-(MFWD)
[LVA14171](#)-(POWER STEERING CYLINDER)(ALL)

ENGINE

BRAKE DISK



[LVA17440](#) -(PTO CLUTCH)(ALL)
[LVA17426](#) -(FRICTION PLATE)(ALL)
[LVU23536](#) -(SEPARATOR PLATE)(ALL)

CLUTCH DISK



[SJ13448](#)

ALTERNATOR



[LVA18613](#)-(ALL)

FAN BELT DRIVE



[LVU29376](#)-(ALTERNATOR)(LGTH = 1112 mm)
[LVU29375](#)-(HVAC)(LGTH = 1508 mm)

BATTERY



[TA15225](#) -(WET CHARGED BATTERY)
(ALL)
[TY26442B](#) -(WET CHARGED BATTERY)
(ALL)



JOHN DEERE
Genuine Parts and Service

CLICK PART NUMBER TO BUY

*See operator's manual for additional details