

REPLACEMENT PARTS GUIDE

4066R Tractor (PIN: 1LV4066R**L*00001-) (Worldwide Edition)

ENGINE



ENGINE OIL

[TY26668](#) (10W-30 PLUS-50™ II) (5.4 L (1.4 gal))

Change Every 400 Hrs or Annually, whichever comes first.



FUEL FILTER

[MIU803127](#)

Change after every 400 Hrs/Annually.



AIR FILTER

[RE68048](#) (PRIMARY)

[RE68049](#) (SECONDARY)

Change every 600 hrs. or annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY6341](#)

GREASE GUN

[TY26183](#)

Change As Required.



OIL FILTER

[M806419](#)

Change Every 400 Hrs or Annually, whichever comes first.



FUEL-WATER SEPARATOR

[MIA885324](#) (SEPARATOR)

[MIU802421](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.



FILTER PAK

[TA25765](#)



DIESEL PARTICULATE FILTER

[MIU803276](#)

AXLE



TIE ROD

[LVA14951](#) (ASSEMBLY)

[LVA14960](#) (LH)

[LVA14959](#) (RH)



ELECTRICAL



KEY

[RE183935](#)



IGNITION SWITCH

[LVA21501](#)



BATTERY

[TY26442B](#) (12 V)



LED WORK LIGHT

[AM143579](#) (OOS) (12 V)

[RE593795](#) (CAB) (12 V)



HEADLIGHT

[R136239](#) (HALOGEN) (12V 60/55 W)

[TA26778](#) (LED) (12V)

FUEL & AIR



FILLER CAP

[AL213202](#)

CAB



CAB FILTER

[MIU10010](#)

Clean or replace after every 50 hours.



RECIRCULATION AIR FILTER

[MIU10011](#)

Clean or replace after every 50 hours.

TRANSMISSION/ HYDRAULIC



TRANSMISSION/HYDRAULIC OIL

[TY22000](#) (John Deere Low Viscosity Hy-Gard™ - 5.5 L (1.5 gal))

Change Every 1200 hours or 3 Years.



OIL FILTER

[RE45864](#) (TRANSMISSION)

[LVA10419](#) (HYDRAULIC)

Change after every 400 Hrs. or Annually.



V - BELT

[LVU29376](#) (ALTERNATOR) (LGTH = 1112 mm, WIDTH = 13.4 mm, TK = 9.6 mm)

[LVU29375](#) (HVAC) (LGTH = 1508 mm, WIDTH = 13.4 mm, TK = 9.6 mm)



JOHN DEERE
Genuine Parts and Service

For Company Use - LV584359

July 2023. Release Date.

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.