

# REPLACEMENT PARTS GUIDE

## 5 Series Tractors - 5310, 5410 and 5610 (TREM III Engine) (India Edition)

### ENGINE



#### FINAL FUEL FILTER

[RE60021](#)

Replace after every 250 hours.



#### OIL FILTER

[RE507204](#) (FOR INDIA)

[T19044](#) (FOR EXPORT)

Replace initially after 100 hours and every 250 hours and annually.



### ENGINE



#### PRIMARY AIR FILTER

[AT171853](#)



#### SECONDARY AIR FILTER

[AT171854](#)

Replace every 250 hours and annually.

### TRANSMISSION / HYDRAULIC



#### OIL ELEMENT

[RE45864](#)

Replace initially after 100 hours and 1100 hours and after every 500 hours and every 1250 hours

# CAPACITIES

## 5 Series Tractors - 5310, 5410 and 5610 (TREM III Engine) (India Edition)

### CAPACITIES (Approximate):

#### Fuel Tank:

..... 68 L (17.9 gal)

#### Cooling System:

##### Cool-Gard™ II

..... 9.5 L (2.5 gal)

### Transmission and Hydraulic System:

#### Hy-Gard™

(5310,5410) (2WD)..... 38 L (10 gal)  
MFWD.....39 L (10.3 gal)

#### Front Axle:

#### Hy-Gard™

MFWD Differential Housing Axle Oil.....4.5 L (1.18 gal)  
MFWD Wheel Hub Axle Oil (Each)..... 0.7 L (0.18 gal)

# REPLACEMENT PARTS GUIDE

## 5 Series Tractors - 5310, 5410 and 5610 (TREM III Engine) (India Edition)

### ENGINE



#### BRAKE DISK

[AL162808](#) (ALL)

[L77358](#) (ACTUATING) (ALL)

#### CLUTCH DISK

[RE242274](#) (PTO) (5310, 5410)

[SJ29351](#) (LUK) (5310, 5410)

[RE258872](#) (PTO) (5610)

[RE258871](#) (LUK) (5610)



#### FAN BELT DRIVE

[R216949](#) (ALL)



#### ALTERNATOR

[RE214808](#) (MICO) (5310, 5410)

[RE234714](#) (MICO) (5610)



### CAB



#### SEAT

[RE73192](#) (BOTTOM) (5410, 5610)

[RE207357](#) (5310, 5410)

[RE246335](#) (5610)

[SJ20516](#) (BELT) (5610)

[SJ18041](#) (BELT) (5310, 5410)

[RE212691](#) (5410, 5610) (WITH ROPS)

### AXLE



#### TIE ROD

[RE176823](#) (CLUTCH PEDAL) (ALL)

[RE271437](#) (MFWD) (5610)

[RE271440](#) (MFWD) (STEERING CYLINDER) (5610)

[RE271441](#) (MFWD) (5610)