

FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

5M Series Tractors - 5065M and 5075M (IT4) North America Edition

CAB

RECIRCULATION AIR FILTER -
[RE195491](#)

Clean after every 600 hours and
replace as per filter condition.



CAB

FRESH AIR FILTER
[RE198488](#)

Clean after every 600 hours and
replace as per filter condition.

ENGINE

PRIMARY AIR FILTER
[RE253518](#)

SECONDARY AIR FILTER
[RE253519](#)

Service after every 600 hours.



ENGINE

FUEL FILTER
[RE533026](#)

Replace after 500 hours.



ENGINE

OIL FILTER
[RE59754](#)

Replace initially after 300 hours and after
every 300 hours (When not using John
Deere Plus-50™ oil and filter). Replace after
every 500 hours (When using John Deere
Plus-50™ oil and filter).

HYDRAULIC

OIL FILTER - [SJ11784](#)

Replace after every 600 hours.



http://www.deere.com/en_US/parts/service/support/filteroverviews

CAPACITIES

5M Series Tractors - 5065M and 5075M (IT4) North America Edition

CAPACITIES (Approximate):

Fuel Tank:

Cab 117 L (31 gal)
 OOS 84 L (22.3 gal)

Cooling System:

Cool-Gard™ II

Cab 15 L (3.96 gal)
 OOS 13 L (3.4 gal)

Crankcase W/ Filter:

..... 10 L (2.6 gal)

**Transmission and Hydraulic System:
 Hy-Gard™**

SyncShuttle Plus™ transmission 53 L (14 gal)
 PowrReverser Plus™ Transmission 53 L (14 gal)
 PowrReverser™ or SyncReverser™
 Transmission 53 L (14 gal)

MECHANICAL FRONT-WHEEL DRIVE (MFWD) AXLE:

Differential Housing 5 L (1.32 gal)
 Wheel Hub (Each) 0.8 L (0.21 gal)

[Return to Filter Overview](#)

