

REPLACEMENT PARTS GUIDE

8RX Tractor(s) Final Tier 4 (FT4) (801001-) - 8RX 310, 8RX 340, 8RX 370 And 8RX 410 FILTER OVERVIEW WITH SERVICE INTERVALS

ENGINE

AIR DRYER (IF EQUIPPED)



FILTER ELEMENT [HXE135862](#)

Replace filter at least every 2 years, regardless of operating hours.

SECONDARY AIR FILTER [RE596318](#)



Replace after every 1000 hours, annually or as indicated, whichever occur first. Interval may vary according to operating conditions).

PRIMARY AIR FILTER [RE596317](#)



Replace after every 1000 hours, annually or as indicated, whichever occur first. (Interval may vary according to operating conditions).

PRIMARY FUEL FILTER FILTER ELEMENT [RE539465](#)



Replace after every 500 hours, or as indicated, whichever occurs first.

OIL FILTER FILTER ELEMENT [RE509672](#)



Minimum hours before first engine oil change 100 hours. Extended engine oil change every 500 hours or annually, whichever come first. The extended 500 hour interval is only allowed if using Plus-50™ II oil with a John Deere filter and diesel fuel with sulfur content less than 15mg/kg (15ppm). If all conditions are not met, change oil and filter at 250 hours of operation.

FUEL WATER SEPERATOR FILTER (IF EQUIPPED) [AT365869](#)



Replace after every 500 hours.

SECONDARY FUEL FILTER FILTER ELEMENT [DZ112918](#)



Replace after every 500 hours, or as indicated, whichever occurs first.



CAB

FRESH AIR FILTER [RE284091](#)



Replacement interval can vary according to operating conditions. Normal service is 1000 hours or annually, whichever occurs first.

RECIRCULATION AIR FILTER [RE593819](#)



Replacement interval can vary according to operating conditions. Normal service is 1000 hours or annually, whichever occurs first.

SCV

FILTER [RE269061](#)



Replace after every 1500 hours.

ENGINE

FUEL TANK VENT FILTER [H216169](#)



Replace after every 1500 hours.

HYDRAULIC

OIL FILTER ELEMENT [RE596661](#) (Qty 2)



Replace after every 1500 hours.

ENGINE

DEF TANK VENT FILTER [H216169](#) (Qty 2)




Replace after every 1500 hours.

DEF INLINE FILTER [DZ110513](#)



Replace after every 3000 hours or every 3 years whichever occurs first.

DEF SUPPLY MODULE FILTER [DZ114640](#)



Replace after every 3000 hours or every 3 years whichever occurs first.



CAPACITIES

8RX Tractor(s) Final Tier 4 (FT4) (801001-) - 8RX 310, 8RX 340, 8RX 370 And 8RX 410

CAPACITIES (Approximate):

Fuel Tank:

..... 924 L (244 gal)

DEF Tank:

..... 37.2 L (9.8 gal)

Cooling System:

Cool-Gard™ II

FT4/T3 42.3 L (11.2 gal)

T2 34 L (9 gal)

Engine Crankcase Oil Volume, Including Filter:

Plus-50™ II

..... 26.6 L (7 gal)

ExactRate™ Tank:

..... 3785 L (1000 gal)

Transmission / Differential / Hydraulic System

76 in, 80 in and 88 in 250 L (66.1 gal)

120 in 260.6 L (68.8 gal)

Axle Housing

76 in 16.5 L (4.3 gal)

80 in 19.5 L (5.2 gal)

88 in 27.3 L (7.2 gal)

120 in 34.1 L (9.0 gal)

Final Drive (Each)

1700 MFWD 3.8 L (1 gal)

Fan Chain Drive Housing

..... 473.2 ML (0.5 qt)

REPAIR PARTS GUIDE

8RX Tractor(s) Final Tier 4 (FT4) (801001-) - 8RX 310, 8RX 340, 8RX 370 And 8RX 410

ENGINE

- 

STARTER
[RE549229](#)
- 

AUXILIARY DRIVE BELT
[R561692](#) - W/O Air Compressor
[R563475](#) - W/ Air Trailer Brake
- 

ENGINE BLOCK HEATER
[AT410692](#) 120V
[RE524675](#) (- 182034), 240V
[RE597086](#) (182035 -), 240V
- 

RADIATOR CAP
[RE312969](#)
- 

BELT TENSIONER
[RE590904](#)
- 

WATER PUMP
[DZ102107](#)
- 

A/C COMPRESSOR
[RE326205](#)
- 


ALTERNATOR
[DZ117724](#) - 330 A
[DZ124395](#) - 250 A
- 


FUEL INJECTION PUMP
[RE543262](#) - Stage III
[DZ123504](#) - Stage V
- 


TORSIONAL DAMPER
[DZ110891](#) - Rear Crankshaft
[DZ110894](#) - Front Crankshaft





CAB

- 

INTERNAL REAR VIEW MIRROR
[RE588734](#)
- 

WIPER BLADES
[R572234](#) - Front, Rear & RH Window
- 


EXTERNAL REAR VIEW MIRROR
[RE586098](#) - LH
[RE586099](#) - RH
- 

TECHNOLOGY MOUNTING SOLUTION
[RE343680](#) - Accessory Mounting
[BRE10015](#) - Cell Phone Mounting
[BRE10255](#) - Tablet Mounting Bracket
- 


GAS CYLINDERS
[RE594521](#) - LH Door
[RE593531](#) - Rear Window

HITCH AND SCV


- HITCH MAINTENANCE**




[R309701](#) - Sway Block, RH
[R274328](#) - Sway Block Wear Plate, RH




[R309702](#) - Sway Block, LH
[R274326](#) - Sway Block Wear Plate, LH



[AXE14245](#) - Hitch Position Sensor
- SCV**



[RE577560](#) - Breakaway Coupler
[R186598](#) - Snap Ring
[RE186600](#) - Seal Kit
- LIFT LINK PINS**



[R169163](#) - Pin
[R107278](#) - Draft Link Ball Stud

ENGINE

- 

BATTERY
[TY25879B](#)