

WEAR PARTS OVERVIEW W660 COMBINE

THRESHING

MY11-22

[AZ58905](#) – RASP BARS

Paired by weight with deep heat treatment for excellent threshing, good drum balancing and long lifetime.

MY11-22

[AXE53048](#) - UNIVERSAL CONCAVE

MY16-18

[AXE68166](#) - HIGH-DIVERSITY UNIVERSAL CONCAVE

Perfect fit and versatility with the adjustable booster bar.

[AXE53100](#) - SMALL GRAIN CONCAVE

MY16-18

[AXE68169](#) - HIGH-DIVERSITY SMALL GRAIN CONCAVE

Exactly welded for easy adjustment and perfect threshing.

MY19-22

[AXE59411](#) - HIGH-VERSATILITY CONCAVE

[AXE59379](#) - CONCAVE INSERT SMALL GRAIN

[AXE59409](#) - CONCAVE INSERT SMALL GRAIN

[BXE10909](#) - ROUND BAR CONCAVE INSERT KIT

High versatility with easy-to-exchange inserts.



STRAW CHOPPER

PREMIUM KNIVES

Induction hardened to resist wear and tear at the punched hole and the cutting edge.

MY11-15

[Z103205](#) - PREMIUM CHOPPER SERRATED KNIFE

[Z103376](#) - PREMIUM CHOPPER SMOOTH KNIFE

MY11-22

[Z105500](#) - PREMIUM CORN SERRATED KNIFE

MY11-15

[Z75874](#) - PREMIUM CHOPPER STATIONARY KNIFE

STANDARD KNIVES

Induction hardened to resist wear and tear at the punched hole and the cutting edge.

MY11-15

[Z77601](#) - STANDARD CHOPPER SERRATED KNIFE

MY11-15, MY19-22

[Z53454](#) - STANDARD CHOPPER SMOOTH KNIFE

MY11-15

[Z42176](#) - STANDARD CHOPPER CORN KNIFE

[HXE13024](#) - STANDARD CHOPPER STATIONARY KNIFE SMOOTH

MY11-22

[HXE13023](#) - STANDARD CHOPPER STATIONARY KNIFE SERRATED

WEAR PARTS OVERVIEW

W660 COMBINE

FEEDERHOUSE

OUTER CHAIN

Made for smooth running, resisting load spikes and minimal elongation.



MY11-15

[AZ63336](#)



[AZ102573](#) (HEAVY DUTY)



MY16-22

[AXE41939](#)

INNER CHAIN

Made for smooth running, resisting load spikes and minimal elongation.



MY11-15

[AZ63337](#)



[AZ102574](#) (HEAVY DUTY)



MY16-22

[AXE41940](#)



GRAIN HANDLING

MY11-22

[AZ101808](#) - CLEAN GRAIN ELEVATOR CHAIN

Made for smooth running, resisting load spikes and minimal elongation.



STRAW WALKER

MY11-15

[AZ45586](#) - BEARING

Original John Deere bearings don't warp, open, crack or break, nor will they seize on the shaft.



JOHN DEERE
Genuine Parts and Service