

**9570 STS COMBINE BALLAST REQUIREMENTS
FOR NORMAL AND EXTREMELY HILLY CONDITIONS**

COMBINE	9570 STS							
	NORMAL (slopes of 15% or less)				EXTREMELY HILLY (slopes greater than 15%)			
CONDITION	NO		YES		NO		YES	
4WD	NO		YES		NO		YES	
FLUID REQUIRED	NO	YES	NO	YES	NO	YES	NO	YES
HEADER								
615 BPU	0	0	0	0	0	0	0	0
615 R	0	0	0	0	0	0	0	0
615 F	0	0	0	0	0	0	0	0
618 R	0	0	0	0	0	0	0	0
618 F	0	0	0	0	0	0	0	0
620 R	0	0	0	0	0	0	0	0
620 F	0	0	0	0	0	0	0	0
622 R	0	0	0	0	4	1,2,3	0	0
622 F	0	0	0	0	3,4	1,2	0	0
625 R	0	0	0	0	NR	1,2,3,4	0	0
625 F	0	0	0	0	NR	1,2,3,4	0	0
630 R	0	0	0	0	NR	NR	NR	1,2,3,4
630 F	0	0	0	0	NR	NR	NR	1,2,3,4
925 D	0	0	0	0	NR	NR	NR	1,2,3,4
693 C	0	0	0	0	0	0	0	0
694 C	0	0	0	0	0	0	0	0
893 C	0	0	0	0	NR	1,2,3,4	3,4	1,2
894 C	0	0	0	0	NR	2,3,4	NR	1,2,3,4
606 C	0	0	0	0	4	1,2,3	0	0
606 C-SM	0	0	0	0	NR	1,2,3,4	3,4	1,2
608 C	0	0	0	0	NR	4	NR	1,2,3,4
BPU = Belt Pickup Platform R = Rigid Platform F = Flex Platform D = Draper Platform C = Cornhead C-SM = Cornhead w/ StalkMaster		0 = No Ballast Required for any Rear Tire Option. 1 = 16.9R26 rear tires. 2 = 18.4R26 rear tires. 3 = 480/70R30 (18.4-30) rear tires. 4 = 600/65R28 rear tires. NR = Not Recommended since machine with header cannot be properly ballasted. Note: Tires requiring fluid must be filled to 75%.						